


On-Screen Display (OSD) Icon Descriptions



A. Brightness:

Selecting the Brightness icon allows you to change the brightness of your display. Making changes to the brightness level does not make the image color brighter but rather makes changes to the background brighter. For example, if your brightness level is too high, your display will not be able to display a black background properly.



B. Contrast:

Selecting the Contrast icon allows you to change the present contrast level to your display. Contrast is the video amplification ratio between noise and the maximum video gain possible. This setting, together with the brightness setting, determines the best image contrast between the background (black level) and the video gain.



C. Palette:

Selecting the Color Palette icon allows you to make adjustments to the color brightness level being displayed. If the color palette is set too high, bright colors may appear white in the display.



D. Reset To Default:

Selecting the Reset To Manufacturer's Default Values icon returns all of the settings (Brightness, Contrast and Palette) back to the original, preset factory levels and overwrites changes you may have made to any of the above display controls.

Please Note: In order to activate the "Reset To Manufacturer's Default Values" simply highlight the correct icon and press the ON/OFF button once. Unlike all other display icon instructions where you use the ADJUST (+/-) buttons to make changes and then the ON/OFF button to exit, the "Reset To Manufacturer's Default Values" is activated simply by pressing the ON/OFF button one time. The bar graph does NOT appear when you select this control function.



E. Exit:

To exit the OSD menu, simply highlight the "Exit" icon. The OSD menu screen will disappear. Audio Control resumes once you exit the OSD menu screen.

Troubleshooting

Consult these instructions for information on how to connect and operate i-glasses VIDEO headsets. Please check the following: Check all connections including power, video and audio. Make sure that your i-glasses cable is connected to the "VIDEO OUT" and "AUDIO OUT" plugs located on your video source. Check your video source (VCR, DVD, Camcorder, etc) to ensure that it is working properly. Don't forget to "Turn On" your video source and to press "Play" when you are ready to use your i-glasses. If the following suggestions don't correct your problem, call i-glasses Technical Support: (800) 339-5287 during normal business hours (M-F 8-5 PST).

Possible Problems and Solutions

No Power to i-glasses. Amber Light is Not Illuminated.

Check to ensure that the power adaptor is plugged into an operational wall circuit. Press and hold down the ON/OFF Button for approximately one second, then release. It may take a few seconds for any picture to appear on the i-glasses displays. Check the cable connection to the i-glasses. Make sure it is seated firmly in place. Unplug the cable from the headset and check to make sure all pins are straight and aligned. Carefully reinsert the plug into the headset and make sure it is seated firmly in place.

The i-glasses power indicator light is on but there is no video image.

Make sure your video source (VCR, DVD, etc) is on and working properly. Make sure that the i-glasses cable is connected to the "Video Out" jack of your video source. Make sure you press "Play" on your video source. Check all connections to make sure they are seated correctly and seated firmly in place.

Power is ON, Video is ON, but there is no audio signal.

Press the volume ADJUST (+/-) button. Make sure the audio (Red and White) cables are connected to the "AUDIO OUT" jacks on your video source device. Make sure the cable is firmly seated into the i-glasses. Check volume control on your source device. If the volume on your source device is turned off, muted or too low, you may not receive an audio signal into the headset.

My TV does not have "Video Out" and "Audio Out" Jacks.

Many older television sets, or newer, inexpensive television sets do not offer "Video Out" and "Audio Out" connections. The i-glasses must be connected to a device which has these outputs, such as a VCR or DVD player. To watch broadcast television with your i-glasses, connect the i-glasses to a device which has a built in TV tuner such as a VCR. DVD Players will only have a tuner if they are DVD Recording devices. Keep your television, VCR, DVD player, and cable antenna hooked up as they normally would be. Simply plug your i-glasses into the VCR "Video Out" and "Audio Out" output jacks, and use the tuner on the source device (VCR) to select the station you wish to view.

Care and Maintenance

Please follow these simple guidelines when caring for and cleaning your new i-glasses VIDEO.

- Store your i-glasses in a safe, dust-free environment. Do not store your i-glasses in any location where they may collect excessive dirt, lint or dust.
- Use care when transporting your i-glasses. We recommend that you use a hard-sided protective case when storing and transporting your i-glasses. Take extra care to avoid scratching or otherwise damaging the optical components.
- Never immerse your i-glasses in liquid of any kind. When cleaning, avoid using common cleaning solutions or sprays. We recommend using a soft, damp cloth and water to gently wipe clean.
- Do not drop, hit, bend or otherwise abuse your i-glasses and accessories.
- Do not leave your i-glasses "On" for extended periods of time or when not in use.
- Do not disassemble or try to repair your i-glasses in anyway. Doing so will void your warranty.
- Use only the AC power supply included with your i-glasses. The use of any other power supply can severely damage the product and will void your warranty. Make sure the power to your i-glasses has been turned off before disconnecting.

Product Use Warning

All i-O Display Systems' Product units have been designed with precision optics to minimize the potential for motion sickness, however certain individuals may experience nausea or disorientation while viewing certain games or videos. If you feel a sense of dizziness or light-headedness discontinue use. Do not use this Product near balconies or stairs, or on uneven ground. In addition, do not use the unit while moving, walking, standing, driving, swimming, operating machinery, or doing anything else that requires your full attention. Warning: Consult your physician before using any i-O Display Systems Products if you, or anyone in your family, has an epileptic condition. A very small portion of the population may experience epileptic seizures when viewing certain kinds of flashing lights or patterns that are commonly present in our daily environment. These persons may experience seizures while watching some kinds of television pictures or playing certain video games, including viewing through i-O Display Systems Products. Persons who have not had any previous seizures may nonetheless have an undetected epileptic condition. Discontinue use immediately if you experience any of the following symptoms while using any i-O Display System Products: eye or muscle twitching, involuntary movements, disorientation, loss of awareness of your surroundings, mental confusion, dizziness, sickness, and/or convulsions.

Trademark Acknowledgements

i-O Display Systems and i-glasses are registered trademarks of i-O Display Systems LLC. Other names and products not mentioned above may be registered trademarks or trademarks of their respective owners. Numerous U.S. and International patents issued and pending. Please check the www.i-glasses.com web page for a list of issued patents. Copyright 2005 i-O Display Systems LLC. All rights reserved.

i-O Display Systems shall not be held liable for technical or editorial omissions or errors made herein; nor for incidental or consequential damages resulting from furnishing, performance, or use of this material. This document contains information protected by copyright.